

# How to design Dust Sensor


2013 Mar.

# To begin with

- ◆ To make sure basic information of GP2Y1010AU0F
  - ◆ Refer to presentation of “ Dust Sensor “ total 13page w/o cover page
    - ◆ Circuit
    - ◆ Variation => Calibration
    - ◆ Mechanical Design Consideration
    - ◆ Power consumption
- ◆ Document
  - ◆ Spec
  - ◆ Application Note
  - ◆ Temperature Drift
  - ◆ Reliability

# Standard Operation


## Finish product: Air purifying system



**No-Dust Condition: Set tentative No Dust Vout**



- (1): refer to the number from monitor sample  
For example less than 1.0V equivalent to 0.05mg/m<sup>3</sup>  
@ monitor sample # 1
- (2) : Vout @ No dust condition by Monitor sample  
For example, 0.8V @ sample #1  
if test box is not clean enough, No dust Vo  
should be calculated as compensation number as follows;  
No Dust Vo' = No Dust Vo - Delta Vo  
Please refer to next page 3



# How to update ? No-Dust Vout

When starting air purifying system as finish product, air cleaner,  
“No-Dust Vout” should be updated accordingly as following conditions;

## No Dust check when starting

- 1, When starting air purifying system like fun-rotation,  
comparing Real Dust Vo with No Dust Vo(tentative one) which was set before shipment.  
if  $\text{Real Vo} < \text{No Dust Vo} \Rightarrow$  replace the Real Vo to No Dust Vo  
 $\Rightarrow$  Then this will be the latest No Dust Vo

## More clean condition

- 2, When operating if find the cleaner condition such as  $\text{Real Vo} < \text{No Dust Vo}$ ,  
 $\Rightarrow$  replace the Real Vo to No Dust Vo  $\Rightarrow$  Then this will be the latest No Dust Vo




## Compensation of unexpected incident

- 3, When operating if find steady Vo for long term,  
 $\Rightarrow$  replace the Real Vo to No Dust Vo  $\Rightarrow$  Then this will be the latest No Dust Vo

# Proposal of calibration for no-dust condition

- **process**

- Sharp makes monitor sample (3pcs)
  - Monitor sample has data of Vout vs. Dust density
  - Data should be shown low density condition such as 0 to 0.1mg/m<sup>3</sup>.
- Manufacture can use this monitor sample and set initial tentative no-dust condition
  - Monitoring the value of monitor sample and convert the Vout to initial tentative no-dust condition for mass production board of Manufacture.



Convert Pr-Vout @ tentative no-dust condition to **Real no-dust Vout** by calibration as follows;  
$$\text{Real No-Dust Vout} = \text{Pr-Vout @ tentative no dust} - \text{delta V}$$

# Variation

## ◆ Calibration

### ◆ No-Dust Vo

- ◆ Refresh/Update as latest cleaner condition
- ◆ Dust Density Vo = Real-Dust Vo – No-Dust Vo
  - ◆ Value of Dust Density can be used for set thresh level of starting fan rotation or segmentation of the Dust density level on Display

## ◆ Compensation


### ◆ Temperature Drift

- ◆ Normalize the value for compensation: from 0 to 50 degree C
  - ◆ Please refer to attached graph of temperature drift

### ◆ Time Aging

- ◆ TBD
  - ◆ can be ignorable ?

# Vout @ No-Dust condition vs. Temperature





# Impact of contamination for Sensor Output

## -Test concept

-To measure the impact of contamination for Sensor Output

## -Test Method

-Take the date of K(Sensitivity) and Vout @ no-Dust for the sensor

-Set the sensor in the test box ( W50 x H50 x D50cm).

-Smoke 1pcs of Cigarette completely and pour the smoke into the test box.

And keep the condition for 20 minutes. => It's the one cycle.

-Repeat above process for N times and take the date of K(Sensitivity) and Vout @ no-Dust for the sensor

Variation of Vout(sensitivity) (%) = ( K(Sensitivity) after N times )/Initial K(Sensitivity)

Variation of Vout @ No-dust (%) = ( Vout @ No-dust after N times/Initial Vout @ No-dust )

## -Note

-This is acceleration test, so it can be equivalent to the real condition of smoking at room.

-Real condition of cigarette smoke = (Size of room) / (size of the test box) X (smoked cigarettes)

-For ex. Size of room( 3.6m X 3.6m X 2.4m )/( 0.5m X 0.5m X 0.5m ) X 300= 74,649 pcs

It can be equivalent to 3,732 days with 20pcs smoking a day.

